

## N5/N5b Pennsylvania Cabin Car Instructions

There are several features on your N5/N5b cabin car that require brief instructions to enhance your enjoyment of your new model. To remove the roof refer to the left photo immediately below, there are small black head screws on either end of the model that need to be removed, the roof will then lift off. The marker light connections shown in the right photo immediately below are polarity sensitive. The lights are LED's and function independently, if either or both markers fail to light when power is applied, simply reverse the connection.



The interior and exterior marker lights can be controlled using the slide switch on the model underbody which is shown in the photo below.

